




Acer Aspire One 722 Keyboard Keys Replacement

A guide on how to replace the keyboard keys on the Acer Aspire One 722.

Written By: Christian Barboza



Step 1 — Battery



- Shut the netbook off (Power down netbook at top left corner).

Step 2



- Close the netbook and flip it over so that the back is facing up.

Step 3



- Slide the button below the battery to the right while simultaneously pulling the battery out.

Step 4




- Remove the old battery and get the replacement battery.

Step 5




- Check the thin grooves on the side of the battery entry and line the replacement battery up to that.

Step 6 — Keyboard Keys




- Use the wedge tool to pluck off the keyboard key.
- ⓘ If it's just a broken key just pluck the broken key out and take the new replacement key and press it down over the mechanism. If you need to repair the key follow the steps below.

Step 7



- With the wedge tool pull up on the upper portion on both sides of the mechanism until it pops off from the key socket.

Step 8




- Take both pivoting pieces of the mechanism and put them together. The smaller piece fits through the inner part of the larger piece and lays in the groove of the larger piece. Once assembled it should be entirely flat.

Step 9



- Position the pivoting smaller piece of the key mechanism in the lower hooks of the key socket. Then slide your finger across the upper portion of the key mechanism so that it locks in place with the upper hooks of the key socket.

Step 10



- Place the key freely on top of the mechanism and press it down firmly until the key locks in place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-26 01:38:29 AM.